


# OS-8020 **GAV** HAVALI TORNAVİDA DIRECT DRIVE



No.	Part No.	Parça Adı	No.	Part.No.	Parça Adı
1	80201	Motor Housing	19	80219	Spacer
2	80202	Spring Pin	22	80222	Internal Gear
3	70103	Air Inlet	23	80223	Planet Gear (3)
4	70104	Trigger	24	30124	Pin (3)
5	80205	Valve Stem	25	80225	Bushing(3)
6	80206	Reverse Bushing	26	70526	Work Spindle
7	70107	O-Ring	28	080227	Ball Bearing (2)
8	70108	Valve Spring	29	70133	Washer
9	80209	O-Ring	30	80247	O-Ring
10	80210	Reverse Lever	31	70110	Exhaust Diffuser
11	80211	Motor Gasket	32	40309	Screw (2)
13	030113	Ball Bearing (2)	33	70534	Clamp Nut
14	80214	End Plate (2)	34	80253	Rubber Grip
15	80215	Rotor	35	QC-01SUB	Quick Change Chuck W/#36 Screw
16	80216	Rotor Blades (5)	36	71946-12	Set Screw (2)
17	80217-13	Pin	37	70935	Set Screw
18	80218-22	Cylinder			

GAV HAVALI EL ALETLERİ SAN.TİC.LTD.ŞTİ  
TEL:0216 540 52 80 / 0549 540 52 80